


ME2008 – On Alarm condition



ALARMS

- If any of the safety features are triggered, the relevant alarm will come on.
- The Display will indicate status of the channel that is in alarm condition, in which case, as a precaution the ME2008 will shut down pump drive of the faulty channel only, allowing for further examination of the problem.
- If the alarm comes on, DO NOT push RESET immediately - observe display and take note of the batch readings and the alarm message.
- WAIT for other channels to complete batch, then push RESET to be ready for the next batch.



- If batcher gets Low Flow Alarm on two successive attempts at batching, then:
 - MOVE THE TRUCK MIXER AWAY FROM THE LOADING POINT
 - stop using that chemical channel; as each attempt doses 2 seconds worth of chemical into the mix.
 - record the quantity displayed on the ME2008 and the batch computer; and
 - ring your local admixture supplier or service agent for advise/service (or attempt to address,



- THIS WARNING GUIDE SHOULD BE DISPLAYED AT THE MIX PLANT FOR THE BATCHER / OPERATOR !!